

Part number	Product name
X3451.1M12*1.25	Hinge bolt
3726010-L38-0000	Intelligent special repair diagnostic instrument
1004012-M01-C01	The first air ring
1004030-M01-C01	Coil spring oil ring assembly
1004013-M01-C01	The second air ring
1104036-6A0-154SB	Fuel intake connection
3509020A36D	Air pressure pump return pipe assembly
1004023-E00-0000	Connecting rod bolt
1007100-E00-0000	Rocker arm mechanism components
3407020-68F-015W	Power steering oil pump assembly
1307010A202-XQ40	Water pump assembly
1111216-73D	Fuel injection pump transmission gear
1009070-L39-JH13	Oil gauge assy
1111228-53D	Fuel injection pump connection flange
1004024-M50-0000	Connecting rod small head bushing
1005015-M60-0000	Crankshaft with oil pump drive gear assembly
1009010AL00-0000	Oil pan assembly
1207130AB81-SF10	EGR intercooler outlet pipe
MM000000-PJ4P	81D four-piece fitting
3509500-B80-SF10	Air pressure pump return pipe assembly
1208100-L3B-0000BW	SCR rear processor assembly
1111228A630-0000	Middle flange of fuel injection pump
1129040-B5L-0000K	High pressure tubing assembly (1)- Pump to rail
1111228A63J-0000	Middle flange of fuel injection pump
1111216-B01-0000	Fuel injection pump transmission gear
3701019AB46-KM5C	Generator regulating support
1306021-M3A-21571J	Thermostat holder
1003106AA01-0000	Rubber seal strip
3701010AB46-ZX10	Generator assembly
1002061EB61-KM20F	Gear house cover - flywheel housing
1008004AA01-0000A	Intake manifold pad
1002016-BF2-0000H	Cylinder liner
1003003BA02-ZY1A	Front lifting lug
1306013-656-YT20	Thermostat cover
1005046CB51-0000	Belt pulley
1208100-A66-KM1A	SCR rear processor Assembly (supplementary drawing)
1008116A202-2030	Hose - Diesel engine intake pipe
1306036-E00-0000	Small loop connecting hose
1008023-68F-3134	Inlet nozzle
1005015-81DF	Crankshaft with oil pump drive gear assembly
1307010-M70-000J	Water pump assembly
1002028-E20-KM1A	EGR cooler inlet pipe 1
1104089-630-0000	Locating pin
1208100-668-21702HCCC	SCR rear processor assembly
1014040-E20-0000	Oil return check valve assembly
1111216-M01	Fuel injection pump transmission gear
1009070A630-SJ10	Oil gauge assy
Q5211230	Round pin
Q5211232	Round pin
1013021B36D	Oil cooler cover plate
1308081BM34-JH84C	Wind shield bracket - Intake side (bottom)
3724080A622-0367	Engine harness assembly
1118130AM40-0000	Supercharger return pipe assembly
1210110-E20-2020F	DOC pre-packaged assembly 6.77X4

3701327C201-0000	Connecting plate - for securing the generator
3750030-454-2090	Water temperature sensor
1118010-L39-JH10HY	Turbocharger assembly
3708010A668-JH70B	Starter assembly
1012100AA02-0000	Oil filter assembly
1308001-B81-JB5A	Fan pad
K1010000-PJZW	4110 spindle tile (sleeve)
1006116-E00-0000	Camshaft intermediate gear press plate
1308053-852-01050	Flanged shaft
1008016AB41-KM10	Intake manifold
1005197-400-0000	☆ Shock absorber bolt
1007024-53D	Valve spring seat
1009010EB35-HT10	Oil pan assembly
1008009-A02-0000	Exhaust pipe outlet pad
1117010-B4L-0000	Diesel filter assembly
1003068-600-000Z	Cover bolt
1307010AB71-HT1A	Water pump assembly
1003066A81D	Damping spring
1013100AA02-0000	Oil cooler assembly
1002121-001-DJ10	Sensor-tachometer (same as PDM1002021-001-DJ10)
1008071-A63-DF1A	Exhaust manifold (supplementary drawing)
1002061D53H-HL10	Gear house cover - flywheel housing
1023011-29D	Tensioning wheel bracket
3701323AB46-KM5C	Regulating bolt - generator
1008016-B5P-YFT1A	Intake manifold
1007100A621-0000	Rocker arm mechanism components
1008042-M4K-088T	Exhaust manifold (2)
1118302-BD1-0000	Supercharger lubricating oil inlet pipe
1009010CB46-SF30	Oil pan assembly
Q1840655	Hexagon flange face bolt (turn trivalent chromium)
1005010-550-0000	Crankshaft component
1007024A001-0000	Valve spring seat
1306021A81D	Thermostat holder
3701200-A0P-HYB10	Generator regulating support assembly
1118065-A0P-0000	Outlet bend support assembly
1117005B471-0001	Wood filter support assembly
1003105BA01-0000	Oil filler plug
1007011A81D	Inlet valve
1005123-051-3050	☆ Flywheel bolts
3701013-B46-SS1A	Generator belt
1023011AM65-073N	Front wheel train support
1002600AA02-0000	Piston cooling nozzle assembly (right)
1008042CB81-0000	Exhaust manifold
1008026-101-0000	Intake manifold gasket
L61S3100-PJGG	Ca6df2-30gg3u-3100 cylinder head accessories
1112020-A02-TX1A	Fuel injector coupling
MMH00000-PJGG	MH0 cylinder head accessories
1004011BB41-0000	piston
1001030-017-0000	Back right support
3509100BB45-HB10	Air pressure pump assembly
3708010AA90-0000	Starter assembly
1002201DA03-0000	Flywheel housing
1008036C473-219A	Intake bend
1005010-407-0000W	Crankshaft component
1305101AA71-KM10	Drain valve handle

1011017AB01-0000	Gasket - oil pump
1005046BB01-KMA3A	Crankshaft pulley
3708010AB4H-YFT10	Starter assembly
1001010AA01-SF1AW1	Right front suspension bracket
1006022-001-0000	Lock washer - camshaft timing gear
Q150B0870F36	Hexagon head bolt
1002420-A0P-HYH21	Oil gauge assembly
1005120-630-3010	Flywheel comes with ring assembly
1001010-101-BH1A	Front mount support assembly (exhaust side)
1006015CE00-0000	Camshaft assembly
1005190A151-ZC30	Shock absorber assembly
1001033AM3A-2080AJHC	Left front suspension bracket
1014050-M01	Oil and gas separator filter element assembly
1207011-E00-0000	EGR intercooler intake pipe
3724030A630-000Y	Engine brake harness
1210103-L3H-0000U	V Clamp gasket
1307010B6BE-11609A	Water pump assembly
1003415AE00-2001	Engine trim cover and tag assembly
3724080-L52-JH10	Engine harness assembly
8103020-66A-JH10W	Cold air compressor assembly
1118137-M60-083N	Bolted joint (1)
1023013-M35-2080A	Transitional belt wheel and tension wheel support
1111010-610-0000J	Fuel injection pump assembly
3724512-M70-000J	Engine harness bracket
1207087AM60-0000	EGR actuator bracket
1118060-800-A76A	Supercharger inlet line assembly
1118010CM50-02000SH	Turbocharger assembly
3407020A624-SJ10	Power steering oil pump assembly
3724082-551-YT1F	Engine harness Assembly 2
1306010-81D	Thermostat assembly
1008023-M34-XZ10J	Inlet nozzle
1013027-36D	Spool - oil cooler bypass valve
1118011-E06-501AKC	Hose - compressor outlet pipe
K3000000-PJZW	4CK spindle tile (sleeve)
1004002-B03-0000	Piston pin
3708010AC10-JH30M	Starter assembly
1207140BB81-501A	EGR valve outlet pipe
1014043-M71-089P	The pressure sensor of the exhaust pipe is connected to the hose
1118030-668-0B92R	Supercharger heat shield assembly
1207100-M60-0000BL	EGR valve and control arm components
3601115AB61-0000	Engine control unit assembly
1005083A017-0000	☆ Gear - crankshaft
1003031E001-0000	Cylinder head cover
1007090-B43-0000L	Valve rocker arm shaft assembly
1009010-B5N-AS1B	Oil pan assembly
1104050-B5Q-YM10Z	Fuel injection body return pipe
1009080-E20-2001	Oil gauge tube and oil gauge assembly
1009010FA09-BF10	Oil pan assembly
1009080-E20-2010	Oil gauge tube and oil gauge assembly
1005123A400-0000	☆ Flywheel bolts
MM6G0000-PJGG	M6G cylinder head accessories
1008074-B41-JB10	Thin nut - exhaust manifold
1005120-L37-JH70	Flywheel comes with ring assembly
Q1821045TF2	Hexagon head bolt
1005190-021-DL20	Shock absorber assembly

1112030-M01	High pressure nozzle assembly
1013073-6BA-0000	Seal washer
3602165-621-0000	Fuel temperature sensor assembly
1112010-81D	Fuel injector assembly
1014019-M00-2060A	Oil and gas separator return pipe
1009025-001-0000	Rear left plate - oil pan
1023035-E20-KE00	Flat idler
3509230AM50-02000	Air compressor energy-saving steel pipe assembly
1008051AL3M-228BHCN	Intercooler inlet pipe support
1006040C201-0000	☆ Timing intermediate gear (A) assembly - camshaft
1118100BA06-WZ1AK	Supercharger assembly
1117010-6BA-0000	Fuel fine filter assembly
1003010AB4V-0000	Cylinder head assembly
1104080-684-SJ10	Return line assembly - Filter to return connector
1012010-M36-055R	Full flow oil filter assembly
3750013AB35-0000A	Gasket for air heater
1008016-598-0000	Intake manifold
1601010-A01-AS2A	Clutch housing and disengaging fork assembly
1008012AA02-CS5A	Intake bend assembly
1007016-M01-C01	Exhaust valve
1002319-53D	Copper washer
1014007-B6C-ZX10	Air intake hose
Q1201035F36S	Double stud
1104160BA01-0000	Fuel injection pump lubricating oil pipe assembly
1007060-53DX	Tappet assembly
1005190-700-0000	Shock absorber assembly
G70M10X35-10.9	Hexagon socket screw (Class 10.9)
1008021-454-0000	Hose - compressor outlet
Q1820855F36	Hexagon flange face bolt
1007082-013-0000A	Intake valve seat
1006015-700-0000	camshaft
1014020BB61-BF1A	Respirator cover plate solder
Q1820880F36	Hexagon flange face bolt
3509014-B4H-YFT1A	Transmission flange - Air pressure pump
1307010AB4H-YFT10	Water pump assembly
1006051-M01	Timing intermediate stack gear shaft
1601310-A3B-DK4DX	Clutch cover and pressure plate assembly
3701322-C11-0000	Generator support
1307007-B5G-0000	Pump inlet pipe
1012200CB6C-0000	Oil filter outlet line assembly
1001012B214-0000	Right rear support
1111010-L3H-0000	Fuel injection pump assembly
1008070-M62-01907	Lower bracket assembly - variable speed operator front bracket
1160340-C20-JH30	Intake line assembly - Intake valve to urea tank
1118040-MH0-0000	Supercharger exhaust gas bypass control valve assembly
2S1006065-E20-0000	Camshaft chain guide assembly
1004011-682-0000	piston
1307032BC00-0000	Pump outlet gasket
1118051D300-0000	Gasket - return pipe flange
1008020-B90-0000	Intake nozzle gasket 2
1111010-45A-XQ30	Fuel injection pump Assembly (9700360903)
1210005AL3H-2020HCCW	Post-processing system components
1601310AB21-CS1CWX	Clutch cover and pressure plate assembly
1307016A402-0000	☆ Backing Plate
1308010-M9G-YM10	Fan assembly

1009010B63J-040B	Oil pan assembly
1306535-M65-0A78N	Diesel filter anti-collision bracket assembly
3708010-A61-JB1A	Starter assembly
1008024-B90-SF10	Inlet nozzle
1012015-420-219Q	Rotary oil filter
1306010A29D	Wax thermostat assembly
1104101-M11-051B	Low pressure tubing gasket
X345520PB	Combination washer
1008042-601-046B	Exhaust manifold
3701010-36DR	Alternator assembly
1601400AE06-501AKC	Clutch cover assy
3724080-L3H-JH27V	Engine harness assembly
1601310-A02-HB1AW	Clutch cover and pressure plate assembly
1001031-L37-2040M	Left front suspension bracket
1005038-222-0200	☆ Oil pump drive gear - crankshaft
1009600-M3A-082HJ	Oil gauge tube and bracket parts
1117011-B4L-0000	Diesel filter element
1011010AB11-YFD10	Oil pump assembly
1007200-A01-0000	☆ Push rod assembly
8102002-B61-DK5A	Bushing - air conditioner bracket
3601011-L00-0000	Stand -ECU
MM4K088TB-PJGG	088TB cylinder head accessories
1023030AB61-DK5A	Wedge idler assembly II
1003046-36DB	Bolts - Cylinder head
1308010-B41-KM10N	Fan assembly
1003061C600-000Z	Cylinder head cover under frame
1009010AB01-KM4A	Oil pan assembly
1004001BA02-0000Y	piston
1005046-C20-2010HC	Pulley - Crankshaft
1001020-A0P-HYB10	Front mount support assembly - exhaust side
1005128ABD1-FD10	Flywheel housing cover plate
1004011A055-0000	piston
1009070-B4H-YFT10	Oil gauge assy
1306009-B4H-YFT1B	Water tank rod bracket
1002044AM80-2010A	Rear lifting lug
1012200AB5H-HMS20W	Oil filter outlet line assembly
1001020AA01-SF1AW1	Left front suspension bracket
1005046-B09-YF3C	Crankshaft pulley
1306013-C20-2010HC	Thermostat cover (supplementary)
1006003-A01-0000	☆ Camshaft thrust plate
1307007-B5V-HL10	Pump inlet pipe
1005120-668-160RJA	Flywheel comes with ring assembly
1305012-81D	Drain switch connector
3701010B101-HN1A	Generator assembly
1104056-M01	Hollow bolt - engine return oil
1111101AM08-0000	Fuel injection pump support - Fuel injection pump
F5211Y55-PJJT	4DF2-14-1Y55 cylinder block accessories
1104030-M80-099C	Intake line assembly - oil pump to fine filter
JBC-13-31001	WIFICAN easy to control diagnostic instrument
1171010BM62-21907	Hydrocarbon metering module assembly (diagram)
1009010A600-0263	Oil pan assembly
1013005A48A-0000	Oil cooler parts
WB810000-PJ4P	B81 four combination accessories
1012024-E00-0000	Seal washer
1111228-470-2030	Oil pump connection flange

1118100AA63-DF10HY	Supercharger assembly
3407020-A61-KM1AF	Power steering oil pump assembly
3724080-M9F-0000	Engine harness assembly
1117050-81DWF	Rotary fuel filter core assembly
3724080-B82-JB10	Engine harness assembly
1118010-L3M-2220MSH	Turbocharger assembly
1111000-013-XGC10	Fuel injection pump assembly 6A160A
WB810000-PJ6P	B81 six combination accessories
3509020-81D	Air pressure pump outlet pipe assembly
1009010A600-4110	Oil pan assembly
1118052-M70-0000	Flange lock nut
1004011AM70-000JF	piston
1306060-640-11063A	Warm air connection
1004011-454-0000	piston
1117010AC10-JH30	Fuel filter assembly
1601310-B90-ZX10X	Clutch cover and pressure plate assembly
1118060A600-YT10	Supercharger inlet line assembly
1023011B81D	Front wheel train support
1208100-696-JH26CC	SCR rear processor assembly
1008033-49P-0000	backstop
1006060-E20-0000	Camshaft chain tension arm assembly
3724050-A66-SF1A	Relay box
8104010B600-0367	Air conditioning compression machine assembly
3509303-668-0B92R	Air compressor intake pipe
1003020-96EJ	Cylinder head gasket assembly
1207020AB81-SL2A	EGR cooler
3509060-152-0000	☆ Water inlet pipe assembly
8102003-B22-JB1A	Air conditioning belt
1129110-720-0000	High pressure oil rail assembly
1208100AL50-0000A	SCR rear processor assembly
1208100AL50-0000B	SCR rear processor assembly
3724410CM70-000J	Motor harness assembly
3509010C671-0382	Air compressor assembly
1002061BE20-2001	Flywheel housing
1308010-M10-3130	Fan assembly
1117010-M10-JH10W	Diesel filter assembly
3509020-C11-0000	Air pressure pump return pipe assembly
1118047-M71-000J	Supercharger exhaust gas bypass valve air hose
3724080AB81-DF2A	Engine harness assembly
1002082AM5B-02001	Bolt - trapezoidal frame
1104080C53H-HL10	Fuel intake line assembly
1002061A47J-1AY146	Gear house cover - flywheel housing
1002022A29D	Oil seal sleeve - cylinder block
1111015-47N-0000	Boost compensator tube assembly
1009031-471-2010	Oil pan seal gasket
1118010BM61-0B1602SH	Turbocharger assembly
1013023-M01	Pressure regulating valve spool
8103010AE00-SF20	Air conditioning compressor assembly
1003033-B05-YF10	Fill the oil cap
1111228-M50-000J	High pressure oil pump connection flange
1008034-M7D-0000	Gasket - Throttle valve
3509030-541-2060	Air pressure pump support
1009026AM54-082T	Turning pad - oil pan
1111102-M80-0000	Fuel injection pump support - cylinder block
3701010-C00-0000	dynamo

3701010-B5N-AS1BM	Generator assembly
3724080-6BE-183QA	Engine harness assembly
1112010-48G-0000BY	Fuel injector assembly
6DLFW-00-000	6DL service specific tools
1011041-81D	Oil pump outlet line
3724026-470-0000	Engine harness bracket 3
1005120-62J-0000	Flywheel comes with ring assembly
1118031BM03-010C	Supercharger heat shield
3701010-53C-XJT20	Generator assembly
1307031AE20-2010	Pump inlet pipe
1111010-D9W	Fuel injection pump Assembly (Wuxi AW pump 6AW410)
1160450A668-0B92R	Weld assembly for urea heating return pipe
3708010-A66-KM1B	Starter assembly
1129045-B21-0000	High pressure tubing assembly (2)- Pump to rail
3509020-62F-0883	Air pressure pump return pipe assembly
1111000-011-SP10	Fuel injection pump assembly (Order No. : 6AW129)
3724080-49J-0000	Engine harness assembly
3602345-M60-0000	EGR temperature sensor Assembly
1111000F001-0000W	Fuel injection pump Assembly 6A439
6307-2RS	Rolling bearing
1008024-M71-1D70PA	Intake nozzle support
1129DDD-630-0000	High pressure tubing assembly
1129095-607-0000	High pressure tubing clamp Assembly (4)
Q32008F36	Hexagon flange nut
1014030-M70-000J	Outlet pipe fitting assembly
1207033-B90-WZ10C	EGR intercooler water inlet hose
1002016B29DH	Cylinder liner
1112011-29D	Fuel injector pressure plate
1023021-81DW	Wedge belt
1002016B29DY	Cylinder liner
1118100BA45-HQ10	Supercharger assembly
1118004-81D	Supercharger inlet pipe gasket
1008046-M01	Long bolt for exhaust pipe
1118010-M18-0E91WWY	Turbocharger assembly
1002200AM50-0000Z	Piston cooling nozzle assembly
1014023-65A-038V	Return pipe support A
3724080B49G-0000	Engine harness assembly
1008016-400-0000	☆ Intake manifold
1118146-MH0-084P	Anti-surge valve outlet hose
1118500-B80-0000HY	Supercharger return oil line assembly
1011013-29D	Bushing - oil pump
1160010EE20-DF10A	Urea tank module assembly assembly
3724080AE00-0000	Engine harness assembly
L64D0000-PJ4P	64D four-piece accessories
1009010-840-0000	Oil pan assembly
1111100AA02-WP1AX	Fuel injection pump assembly
3509010A001-0030	Air compressor
1210100-M60-21767HCACT	Rear processor assembly
1118131-E06-2001	Compressor outlet pipe
L64D0000-PJ6P	64D six combination accessories
1013010A101-0000	Oil cooler assembly
1008042AM70-000J	Exhaust manifold middle section
1007175-81DY	Rocker arm shaft assembly (4, 5, 6 cylinders)
1008077AM60-21767	Bracket - Heat Shield (3)
1308010AL3H-JH10C	Electrically controlled silicone oil fan assembly

3810020-B81-YT10	Oil pressure alarm sensor
3509061-152-0000	Water inlet hose
1129DDDAB35-0000	High pressure tubing assembly
3724416DM60-0000	Engine harness bracket 6
1011052-M5B-02001	O-shaped rubber seal ring
3509010-49W-JH50	Air compressor Assembly (supplementary drawing)
1118010-E00-2001	Turbocharger assembly
1007165-M60-0000	Rocker arm shaft assembly (one, two, three cylinders)
1143010-M70-000JM	Pressure regulator to air rail intake pipe assembly
1002017-001-0000	O-type rubber seal ring
Q61906F36	Hexagonal tapered plug
3509286-M35-01509	Air compressor intake pipe
1308010-M34-3131	Fan assembly
1002064-E00-0000	Seal washer
1104050-E00-0000	Fuel injection body return tubing assembly
1013033-M01	Bolt - oil cooler body
N8230000-PJ4P	823 four-piece accessories
1008016AB21-0000	Intake manifold
3701011-B81-SL2AL	Vacuum pump connection
1013005-556-BF10	Oil cooler parts
1303019-002-0010	Small loop connection hose
1307022AL56-JH20	Pipe joint body
1003052-B90-0000	Snorkel gasket
3602060A630-0000S	Engine speed sensor assembly
1009010A013-HL10	Oil pan assembly
1207032-M70-000J	cannula
2S1207020-E20-0000	EGR cooler assembly
1118100AB03-5010	Supercharger assembly
2000120-026-LS10	Muffler support assembly
1308010-M34-XZ10J	Electrically controlled silicone oil fan assembly
1002061-M40-0000	Gear house cover - flywheel housing
1022021-700-0000	Second order equilibrium axis
3724080-551-2020	Engine harness assembly
3724092BL3H-0000B	Integrated post-processor harness assembly
1002056A81D	Crankshaft front oil seal seat
1118080A455-R385	Supercharger return oil line
1014391-M70-000J	Crankcase outlet pipe pressure sensor bracket
1005120-432-0000	Flywheel comes with ring assembly
1007011-BF2-0000	Inlet valve
3407020-L51-3100	Power steering oil pump assembly
1308032AM00-2060A	Fan belt
1112010-734-0000	Fuel injector assembly
1118120BM70-000J	Supercharger inlet pipe assembly
1160401-640-01063A	Urea return connector
3602175-M50-0000	Rail pressure sensor
8104010-61Y-0000	Air conditioning compressor assembly
3407020AB81-JB4CR	Power steering oil pump assembly
1005060-E00-0000N	Rear oil seal
1014030A6BA-0000	Active oil and gas separator
1005120-460-0000	Flywheel comes with ring assembly
3701327-53D	Bolt - For fastening alternator
1306575AM65-0A78N	Engine inlet steel pipe rear support assembly
1001020-A5J-KM3A	Front right bracket assy
1306043-M54-082T	O-type rubber seal 45.8X5.3
1308032-L3B-0000	Fan belt

3408040-600-400P	Lubricate oil pipe assembly
1118010-L3P-2250MSH	Turbocharger assembly
1306023-M01	Intermediate nozzle
1023021B36D	Wedge belt
3708010AB45-HG10M	Starter assembly
1112030-630-0000K	High pressure tubing connector assembly
1104030A640-0000	Intake line assembly - oil pump to fine filter
3407020-L30-LK10	Power steering oil pump assembly
3724080FM50-02000	Engine harness assembly
3509010B454-310AL	Air compressor assembly
3509284-M3A-21901JHC	Air compressor inlet hose
1006065-E20-0000	Camshaft chain guide assembly
1002061-L31-XJ10	Gear house cover - Flywheel housing (supplementary drawing)
1005048-M50-0000	Shock absorber bolt
1008070-M55-092W	Bracket assembly - Connecting tube
1117010A557-JH80W	Fuel filter assembly
1012010-M18-054W	Full flow oil filter assembly
1117012-C10-JH30	Fuel differential pressure switch
MM600000-PJ4P	M60 four-piece accessories
1006021A550-0000	Timing gear - camshaft
1023021-M80-2010B	Wedge belt
1007021-E00-0000	Valve spring
3509010AL51-3100	Air compressor assembly
MM600000-PJ6P	M60 six combination accessories
1003031-M50-02000	Cylinder head cover housing
1112010-96E	Fuel injector assembly
1005046-B81-501A	Belt pulley
1004BBB-A71-0000	Piston ring assembly
1207115AB21-0000	EGR intercooler intake pipe
1111100-A02-CS3A	Fuel injection pump Assembly 4AW524E
1207011-M71-000J	EGR valve inlet gasket
1207048-M71-02024	EGR outlet pipe clamp
1011005A051-0000	The oil pump comes with a gear assembly
1111010A47J-229KAL	Fuel injection pump assembly BP5D50A
1146026-M4Q-0000	Connecting hose
1009010AE06-501AKC	Oil pan assembly
1205010A65E-0000C	Oxidation catalyst assembly
1205010A65E-0000D	Oxidation catalyst assembly
1118110A47L-325F	Bellows assembly
1014040B62G-0A46B	Connecting tube assembly
1002402-M10-0000	Gasket -SCR water intake connection
3602105-M70-0000	Intake pressure temperature sensor assembly
1307019-81D	Bolts - for water pumps
3509020A614-0435	Air pressure pump return pipe assembly
1004BBB-6BA-0000A	Piston ring assembly
1111107A101-JH50	Inlet tubing coupling body
3701010-B90-SF22	Generator assembly
Q401B10F36	Plain washer
1210100-E20-0000ABW	Rear processor assembly
1013010-53DY	Oil cooler assembly
1007001-A61-0000	Inlet valve
1104020-730-0000	Fuel line assembly - Filter assembly to fuel injection pump
1207020AE06-0000	EGR cooler assembly
1005190B53D	Silicone oil shock absorber
1118500-B21-0000WY	Supercharger return oil line assembly

1111015-M14-0000	Electric control unit pump assembly
1208005-668-206DAHC1CC	SCR post-processing system components
1208005-668-206DAHC1CY	SCR post-processing system components
1118060-403-0010	Intake line assembly - Supercharger
1104060A29D	Lubricate oil pipe assembly
1007011-96EH	Inlet valve
1006045-E00-0000	Timing intermediate stack gear shaft
1003010-B35-0000X	Cylinder head assembly
3601115-550-0000	Central controller assembly
1003040CB81-0000	Cylinder head cover supply parts
X340316X22	Copper washer 16X22
1008033-MH0-0000	Throttle - air intake connection hose
2S1118091-6BE-0000	Supercharger gasket
1308061-M35-JH60	Fan transition pad
3408012-M00-0001	Drive shaft housing
4DWFW-00-000	4DW service dedicated tools
3602130-BF0-0000	Camshaft position sensor
1129DDD-470-0000	High pressure tubing assembly
1111010-M81-0000W	Fuel injection pump assembly 6PH122
1023015-M70-000J	Flat idler assembly
3407020AE06-501AKC	Power steering pump assembly
1104160AB90-000C	Fuel injection pump lubricating oil pipe assembly
1112013-M01	Fuel injector clamp bolt
F485025E-PJJT	6DF3-16E3U-025E cylinder block accessories
3602180-607-0000H	Electronic oil pressure sensor
1210100-M62-2Q5122HCACT	Rear processor assembly
Q72216F36	Bowl plug
1002061AE20-501AK	Flywheel housing
1129080-81D	High pressure tubing assembly II - High pressure oil pump with high pressure
Q72228F36	Bowl plug
1207112-M71-000JD	Gasket -EGR water access hole
F5340000-PJJT	CA4DF2-12GG2 cylinder block fittings
3509284-M01	Air compressor intake hose
1004011AM66-000JZ	piston
8103020A6A0-206DAHC	Cold air compressor assembly
1118302-B90-SF10	Supercharger lubricating oil inlet pipe
3602070-470-JK10	Electronic throttle assembly
1104060-155-0000S	Oil pipe assembly
1111010AA09-BF10	Fuel injection pump Assembly 4A163
1009070-B90-WZ10	Oil gauge assembly
1009053A29D	Oil gauge tube seal ring
MM000001-PJPTO	PTO drive shaft assembly accessories
MM70000JC-WXB-PJDP-S	Gasket bag
1002061AE06-501AKC	Flywheel housing
1209100-C11-2020BT	POC rear processor assembly
1111100BB4L-0000H	Fuel injection pump assembly
1208100-M35-2A1526HCCT	SCR rear processor assembly
1306021-624-XJ10	Temperature regulator body (supplementary machining drawing)
1307010-49F-2010A	Water pump assembly
1013005-440-0000	Oil cooler parts
1207056-M71-000J	EGR intake pipe support
1012015-017-XZ20	Rotary oil filter element
3602150C681-0000	Intake temperature sensor assembly
3407020-471-XJ31	Power steering oil pump assembly
1112010-681-0000	Fuel injector assembly

3724080-581-1BY109	Engine harness assembly
1104090BL31-2030	Total return tubing assembly
MMH00000-PJ6P	MH0 six combination accessories
3509100-B90-LZ1A	Air compressor Assembly (supplementary drawing)
LL000000-PJ6P	CA6DLD-24E3 six combination accessories
3750010-C10-0000	Air heater assembly
1023021-29D	Tensioning wheel pressure plate
Q40110F36	Plain washer
3701010-471-JH1A	Generator assembly
1104050A101-0000	Fuel injection body return tubing assembly
3724080AB81-504A	Engine harness assembly
1005015-E06-2001	Crankshaft assembly
3602155B607-0000	Temperature sensor assembly
3701013-M01	Generator belt
3509100-B81-YT10	Air compressor assembly
1008120A490-0000	Throttle valve
1017100-013-HL10	Centrifugal oil filter assembly
1010010-6A0-206DAHC	Oil collector assembly
3509010C671-2010	Air compressor assembly
3724080C6A5-1B82RC	Engine harness assembly
3509050-53DK	Oil intake line assembly - Air pressure pump
3701013-700-0000A	Generator belt
3509044-101-JB3C	Air compressor belt
3701010AE06-2050	Generator assembly
4DXFW-00-000	4DX service dedicated tools
1104082-81D	Hinge bolt M12X1.25
L6BA0000-PJ4P	CA6DL6-38E62 four combination accessories
1012100CE00-0000	Oil cooling filter module
1118148AM71-070P	Anti-surge valve outlet hose
1104050-L37-JH10	Fuel injection pump inlet line
1010020-E00-0000	Oil collector bracket
1003010-520-0000A	Cylinder head assembly
1150035-650-0000	Connector - Connect the intake pressure compensation pipe
1207087BM60-0000	EGR actuator bracket
1112032A621-0000	O-ring - High pressure tubing nozzle assembly (assembly belt)
1002420AA5J-SS1A	Oil gauge assembly
3509100-B90-WZ10	Air compressor assembly
1111010-A16-000PWF	Fuel injection pump assembly 4AW189
XA010000-PJJD	A01 Body positioning pin assembly
1118080BL39-JH10	Supercharger return oil line assembly
1601310-001-201BH	Clutch cover and pressure plate assembly
1174010-6BF-21911HC	Hydrocarbon Injection Piping - Metering Module to Injection Module
XA010000-PJJT	A01 cylinder block fittings status
1009010D81D	Oil pan assembly
3602560-C20-0000	Urea pressure sensor
1005190AE06-0000	Shock absorber assembly
1203071-M62-21760	Connecting pipe
1009010C101-0000	Oil pan assembly
XA010000-PJLW	A01 Connecting rod tile
1023021-36DB	Wedge belt
1104160AB21-0000	Fuel injection pump lubricating oil pipe assembly
1004011-BF0-0000	piston
1308010-101-HL10	Fan assembly
3509100-A63-DF10D	Air pressure pump assembly
1007016-49Y-0000H	Exhaust valve

1010010CB21-0000	Oil collector assembly
1002214-E00-0000	Bolt-piston cooling nozzle assembly
1008043-471-0001	Seal ring - exhaust pipe
1009070AM50-21587J	Oil gauge assy
3509284-M50-02000	Air compressor intake
1118080-64J-01058	Supercharger return oil line assembly
3509010-585-JH31	Air compressor assembly
1009010-E06-501AKC	Oil pan assembly
1308010-48K-HL10	Fan assembly
1003012-650-0000	Intake valve seat
1208100-L38-JH20BW	SCR rear processor assembly
1008061A621-0000	Exhaust pipe heat shield
3601115-L50-0000	Engine control unit assembly
1208005AM3A-21572JHCCT	SCR post-processing system components
Q617B10F36	Hexagonal head plug
1207075B6BA-0000	Venturi tube assembly
1013100AA02-0000Y	Oil cooler assembly
3701010BB05-YF10	Generator assembly
1005038-455-H410	Oil pump drive gear
1117010-B01-0000K	Rotary diesel filter
1009060-C21-JHK10	Oil gauge tube assembly
1111015-E00-0000	Fuel injection pump transition plate
1003107-B01-0000	Nut - cylinder head cover
1005046-B4D-AS10	Belt pulley
1307010BB42-CS7BWX	Water pump assembly
1012200-B4Q-YFT2B	Oil filter outlet line assembly
1001010-B5G-HL10	Front mounting bracket (exhaust side)
1007012-53DC	Exhaust valve
1307010CB51-0000	Water pump assembly
1004011-B4L-0000Z	piston
WB4L0000-PJ4P	B4L four combination accessories
1005131-A0P-HYB10	Bearing sleeve
1005131-A0P-HYB20	Splined sleeve
1001031B600-070A	Left front suspension bracket
1003031-668-0000	Cylinder head cover
3509001AA02-0000	Air pressure pump support
1005120-471-2010	Flywheel comes with ring assembly
1307003AA01-0000	Air pressure pump belt
1002010AA01-0000	☆ Idler parts
3701322A002-0010	Generator support
1005027B300-0000	Idler shaft
3701031BB6C-SL40	Connecting plate - generator
3602175-M60-0000	Rail pressure sensor
1011068B001-0000	gasket
1008025-E00-0000	Gasket for intake nozzle
1118060-M65-02018	Supercharger inlet line assembly
3509284-M65-073N	Air compressor inlet hose
XA010000-PJQD	A01 Paper pad set
1104030-53H-0000	Fuel line assembly - fuel injection pump to wood filter
1014038-591-YT10	Vent hose
1104030-53H-000A	Fuel line assembly - Feed oil pump to wood filter
1005120A474-229A	Flywheel comes with ring assembly
1005120-470-0000	Flywheel comes with ring assembly
1007035-M40-0000	Exhaust valve stem seal ring
1013019B001-0000	Oil passage seal ring

1012010-017-XZ20	Rotary oil filter assembly
1111017-M60-0000	Oil metering proportional valve
3509020A29D	Air pressure pump return pipe assembly
1160100DE22-WZ11A	Urea tank module components
1210210-E20-DF10F	DPF pre-packaged assembly 7.5X5
1013023-53D	Copper washer
1210100-E20-WZ10ABW	Rear processor assembly
1008058-L35-2020M	Exhaust manifold heat shield right
1111010-B5N-0000ELK	Fuel injection pump assembly
1007090-B43-504AWL	Valve rocker arm shaft assembly
1003038BE00-0000	Bolt - cylinder head cover housing
1111109-E00-YF1A	Oil inlet pipe
1003022AB21-0000	Gasket assembly
1117010-BF1-HL10	Diesel filter assembly
1011068-C00-0000	gasket
1307010-101-HYB10	Water pump assembly
1205200-M72-01612	Catalytic converter assembly
1104050AC20-2010HC	Intake line assembly - fuel injection pump
2S3601027-6BE-0000	Double stud -ECU
1104050C470-0000	Injector return line assembly
3724080-6BG-25241N	Engine harness assembly
1305010-440-JH10	Drain switch assembly
1118094-81D	Gasket - supercharger return oil line
1023031-E00-0000	Wedge belt
1005060-M01	Crankshaft rear oil seal assembly
1306023-29D	Intermediate nozzle
1117011-B90-000CJ	Fuel fine filter element
1002420-A5J-KM3A	Oil gauge assembly
1012010B700-0000	Oil filter assembly
1308032-302-YX10	Fan belt
1111010-013-HL10H	Fuel injection pump assembly
Q61902F36	Hexagonal tapered plug
Q340B10F36	Type I hexagon nut
1308020-E00-WZ10	Fan base assembly
1118145AM71-1D70PA	Exhaust gas bypass control valve outlet pipe assembly
1008100-101-0000	Air heater
1308032A003-SF10	Fan belt
1111015-204-0000	Pressure compensator tube assembly
1118010-690-0AK36	Turbocharger assembly
1004BBB-B43-0000	Piston ring assembly
1118010AM50-0000SH	Turbocharger assembly
1005120-721-YT10	Flywheel comes with ring assembly
K0220000P-PJ4P	CA6113 Top four combination accessories
1118146AM70-0000	Anti-surge valve control hose
1003048-001-0000	☆ Washer - cylinder head bolt
1003031-MH0-0000	Cylinder head cover cover
1306013-M00-2060A	Thermostat top cover
F4390000-PJ4P	6DF2D-14G four combination accessories
1306031-C11-2010	Warm water valve seat
F4390000-PJ6P	CA6DF2D-14G six combination accessories
1005120-M00-0001	Flywheel with tooth ring assembly
3701320AB46-SS1A	Generator support
1003068-M01	Cover bolt
1004011-439-0000	piston
1011014DB01-0000	Driven gear - oil pump

1001033-M65-073N	Front mounting bracket
1005120-600-0263	Flywheel comes with ring assembly
1002314DA01-0000	Timing pointer
1002081A621-JF10	Ladder steel plate
1008036A451-2190	Intake bend
1013001AA01-0000A	Oil cooler cover gasket
1003012A81DA	Intake valve seat ring
1002061C550-0000	Gear house cover - flywheel housing
1009070AB5V-0000	Oil gauge assy
1118400-B5X-YFT2B	Supercharger oil pipe assembly 2
1002044B81D	Rear lifting lug
1002101AA71-0000	Cylinder liner
3701100-A0P-HYB10M	Generator assembly
1005046-M10-01085	Crankshaft with multiple wedges
1005125-53H-000A	Flywheel tooth ring
1002074AB61-DK5A	Gear chamber cover gasket
1003108-B01-0000	Gasket - cylinder head cover
1009010AL30-SJ10	Oil pan assembly
1160220BE20-DF10	Urea tube assembly *1.6m(urea pump - urea nozzle
F541HQ10-PJJT	CA4DF2-13-HQ10 cylinder block fittings
1129DDD-M80-0000K	High pressure tubing assembly
WB210000-PJ4P	B21 four combination accessories
1014025DE00-WZ10	Air hose
3701010-B81-501AC	Generator assembly
3724080CE20-2001	Engine harness assembly
1160010AA51-0000	Urea tank assembly
3701010BE00-WZ20	Generator assembly
1308032-B81-501AF	Fan belt
1207020-BA0-0000	EGR cooler
MM500000X-PJ4P	M50 4-pack accessories
L6A00000-PJ4P	CA6DL3-37E5 four combination accessories
1111000BB41-SF20	Fuel injection pump assembly
1160014-M50-02000	support
1307010-M50-091R	Water pump assembly
WB210000-PJ6P	B21 Six combination accessories
XA010000-PJZW	A01 Spindle tile (sleeve)
6302ZZ	Single row deep groove ball bearing
1104080A61G-CG10	Fuel line - fuel tank to delivery pump
1004BBB-454-0000	Piston ring assembly
Q1841075TF2	Hexagon flange face bolt
1306011-M71-1D70PA	Thermostat top cover
L6A00000-PJ6P	CA6DL3-37E5 six combination accessories
3504010AM34-JH90C	Exhaust brake valve
3509010B602-2030	Air compressor assembly
1104160-E20-0000	Fuel injection pump lubricating oil pipe
1158011-M54-JH80	Support for compressed gas filter
1207100-B81-0000XT	EGR valve
1306020AB90-YT50	Warm water valve switch assembly
1111017-B81-0000	Oil metering proportional valve
1151021-M70-000JM	Pressure regulator support
3509010-520-2020T	Air compressor assembly
1008120-M7D-0000	Electronic throttle assembly
LC202010HC-PJJT	CA4DLD-18E5-2010HC cylinder block accessories
3509010A696-JH20W	Air compressor assembly
3509030AM50-02000A	Air pressure pump inlet pipe assembly

1118060-61S-3100	Supercharger inlet line assembly
2S1014010-E20-0000	Oil and gas separator assembly
1004020AM70-000J	Connecting rod assembly
1014039-601-046BL	Rubber hose
1118010-B5T-YFT2B	Supercharger assembly
1311036-624-JH10	Return pipe connection
1160010-L3H-JH10C	Urea tank module assembly assembly
1111012-L50-0000	O-type rubber seal ring
3407022-81D	Cover plate - Power steering pump
1308032-6B5-0000	Fan belt
1118091BMH0-0000	Supercharger gasket
3701010-439-DL10	Generator assembly
1003048-M60-0000	Cylinder head short bolt
1207011-580-0000	Gasket -EGR valve
1207020-M60-0000	EGR cooler assembly
XCJW15W/40-4L	Jinwei Tin Diesel Special Oil (4L)
1004023-29DBZ	Connecting rod bolt
1005100BA73-AS10	Flywheel assembly
3701010-B61-BF3A	Generator assembly
1306021AM62-2Q5122HC	Thermostat holder
3724080-A0P-HYH23	Engine harness assembly
1601010-B3D-501A	Clutch housing assembly
1002061BB61-JB20	Gear house cover - Flywheel housing (supplementary drawing)
1007120B53D	Exhaust valve rocker arm assembly
1003031AM4K-088T	Cylinder head cover housing
1308041-630-114BA	Fan support
1306011AE20-2001	Thermostat holder
1008024-B61-BF1A	Exhaust pipe cover plate gasket
1146041AMH0-0000	Mixer assembly intake pipe
1005120-B4R-YFT20	Flywheel and ring assembly
1307010DB59-AS10	Water pump assembly
1009002AA01-0000A	Oil pan gasket
1002061BB57-AS10	Gear house cover - flywheel housing
1003013-81DY	Exhaust valve seat ring
3509100CA02-ZC10	Air pump assembly (supplementary drawing)
1001032B640-1A70UF	Right front suspension bracket
1007016B36DC	Exhaust valve
1307100AA01-KM1A	Water pump assembly
1005037B001-0000	☆ Timing gear and oil pump drive gear - crankshaft
1111001-A37-0000	Fuel injection pump gear
1009012AB5X-XJT3H	Oil pan (supplementary drawing)
1007110-630-000Y	Intake valve rocker arm assembly
1002072AB5G-0000	Gear chamber gasket
3701010-B59-AS10C	Generator assembly
1601210-A05-2060Y	Clutch driven disc assembly
1118010-MK1-0000BW	Turbocharger assembly
1002061-621-4110	Gear house cover - flywheel housing
3603004BM70-0000	Spark plug
1023021A81D	Wedge belt
1118010BE06-2001	Turbocharger assembly
1111206A550-0000	Gasket - Flange for oil pump
1002061-C20-2010HC	Gear house cover - flywheel housing
Q5500625	Half-round key
1208100-A51-0000B	SCR rear processor assembly
1207073-M62-01907	Bracket - Connecting tube

1118005AE00-2001	Exhaust manifold
1111010-96E	High pressure oil pump assembly
MM000000-PJTW	81D CAM bearing bush (pair)
1003018-49X-KE00	Jam up
1118112-L3H-JH10C	clamp
1118130AM70-000J	Supercharger return pipe assembly
1118015-650-0000	Compressed air pressure reducer
1210210-L3H-2020HCF	DPF pre-packaged assembly 10.5X7
1002017-E00-0000	Main bearing cover positioning sleeve
3701010-B81-503AF	Generator assembly
1003031-L3H-0000	Cylinder head cover
1002036B36D	Thrust plate
1207072BMH0-0000	EGR Valve seat Pipe support (3)
1112306-E00-0000	Fuel injector gasket
3708010-720-SJ4A	Starter assembly
1017015-29DF	Rotor component
1017015-29DM	Rotor component
1002162AA01-0000	Rear oil seal
1009026-M50-02000	Turning pad 1- Oil pan
1014010-E00-0000	Intake joint
3701013-600-0263A	Generator belt
1008110BA01-WZ1A	Intake nozzle assembly
1006070-C00-0000A	Timing intermediate gear assembly - fuel injection pump
1118302AB42-CS3A	Supercharger oil pipe assembly
1008042-53H-LG10	Exhaust manifold (supplementary drawing)
3509003AB02-501ATW	Idler gear shaft
1008110-A06-WZ5AU	Intake nozzle assembly
K1010000-PJTL	CA4110/125 camshaft fittings
3701324-B71-5010T	Generator limit block
1002161AA01-0000	Rear oil seal seat
1117010A29DB	Rotary fuel filter assembly
3509200AA01-0000	Air pressure pump intake tubing assembly
8102001DB61-DK5A	Air conditioner bracket
1009075-M65-XZ10	Oil gauge tube support assembly
1007110-29D	Intake valve rocker arm assembly
1118230-M70-000J	Supercharger - exhaust manifold gasket assembly
1005181-47S-205CA	Thrust bearing plate
1007161-M71-000JD	Solenoid valve insulation cover
1117005ABA0-DS30CJ	Oil water separator assembly
1009070-E00-KM1A	Oil gauge assy
1002050-M01	Crankshaft front oil seal assembly
3509010A460-0000	Air compressor assembly
1104090-L37-JH10	Total return tubing assembly
3602140-490-0000	Intake air temperature pressure sensor
1003048-M60-0000L	Cylinder head bolt
1008025BB90-WZ10	Intake nozzle 2
1002044-M10-01062	Rear lifting lug
3602170-720-0000	Camshaft position sensor
3407020-M14-1082VA	Power steering oil pump assembly
3509061AM50-02000	Screw in connector - air pressure pump outlet pipe
1117050-M00-2060AWF	Rotary fuel filter core assembly
Q617B22F36	Hexagonal head plug
1207063BMH0-0000	EGR Valve Seat Pipe support (2)
1306021AL31-2030	Thermostat body
3602150B681-0000	Intake temperature sensor assembly

1207135-M71-0D70P	EGR cooler outlet pipe assembly
3701340A53H-HL10	Vacuum pump return tubing assembly
1305010-201-0000	Drain switch assembly
1001010-E00-2001L1	Front suspension bracket (intake side)
2S1104010-L3H-0000	Oil return pipe Assembly (1)
1003032-49X-KE00	Gasket strip - cylinder head cover
3701013-600-0263B	Generator belt
1207015AE00-0000	EGR intercooler outlet pipe
3509010B671-2010	Air compressor assembly
1003020-M40-0000R	Cylinder head gasket assembly
1008042D600-3020	Exhaust manifold
1009070-403-2090	Oil gauge assy
3407020AA61-DF1A	Power steering oil pump assembly
1150073-M70-0000	nozzle
3601115-B5V-0000	Engine control unit assembly
1111216A580-0000	Fuel injection pump transmission gear
1014011-M50-000J	Gasket - oil gas separator
1009060A29D	Oil gauge tube assembly
3701010-L00-0000	dynamo
1003010BB61-0000	Cylinder head assembly
1305010-53H-HL10	Drain switch assembly
1207100-B21-0000XT	EGR valve
1104050AE00-2010	Fuel injection body return tubing assembly
Q1840840F36	Hexagon flange face bolt
1104030-M80-0000W	Intake pipe assembly - filter to fuel injection pump (with Weifu pump)
1207012-E00-0000	EGR intercooler air inlet gasket
1008061A81D	Exhaust pipe heat shield
1117002D550-0000	Wood filter holder
1012100BE00-0000	Oil cooling filter module
1009070-600-070A	Oil gauge assembly (Process requisition)
1118010BB21-5010WY	Turbocharger assembly
1308032-6BE-1Z41NJA	Fan belt
MM34JH70J-PJ4P	M34 four-piece accessories
1129DDD-C00-0000	High pressure tubing assembly
1005071-81DB	Flywheel bolt
1001025-A01-ZC20	Front mount cushion assembly
1008016-B4H-YFT10	Intake manifold
1002071BB81-DK5A	Gear room
1307100-A0Z-AS10	Water pump assembly (supplementary drawing)
3701011-E00-WZ10	Accessory bracket (supplementary drawing)
1003030A6A0-000C	Cylinder head cover assembly
1601026EA01-YK10	Clutch housing
1307010CB59-AS10	Water pump assembly
1006016-840-0000	camshaft
1002420DA01-0000	Oil gauge assembly
1001011-M50-02000	Front mounting bracket
1005100CA03-0000	Flywheel gear ring assembly
1001032A600-070A	Right front suspension bracket
1003047A201-0000	☆ Cylinder head bolt
1003014-M01-C02	Valve guide
1011005-L3H-2020HC	Oil pump component
1007015-630-000Y	Exhaust valve cross arm assembly
1002101-B03-0000	Drain valve socket
1307016-B71-HT1A	Backing plate
1010010-B05-YF10	Oil collector assembly

3724092-E20-501AKB	Integrated post-processor harness assembly
1005124-M54-02009	Rolling bearing 6206
1118080AM40-0000	Supercharger return oil line assembly
1104090A53H-HL10	Fuel return line assembly
1207011AB81-0000	EGR valve intake port gasket
1306012A101-0000	Gasket - thermostat holder
1013021-29D	Oil cooler cover plate
1308032-42A-SJ10	Fan belt
3701315AB81-SF10	Generator support assy
3701013AL00-0000	Generator belt
3810020-450-JH20	Electronic oil pressure sensor
1011051AM5B-02001	Oil pump outlet pipe connector
1005037A001-0000	☆ Timing gear
1002075A472-0000	Gear chamber cover cover cover assembly
1001031-61S-3100XZ	Left front suspension (supplementary picture)
1005038-471-2010	Oil pump drive gear - crankshaft
1306013-M1B-01104A	Thermostat top cover
1111101A001-0000	Fuel injection pump support
1002513-A45-HQ10	Respirator return connection
1003040BB11-YFD1S	Cylinder head cover supply assembly
1014100-B6C-ZX10	Respirator assembly
LL000000-PJ4P	CA6DLD-24E3 four combination accessories
3601115A621-0000	Engine control unit assembly
3701010-B61-JB20	Generator assembly
1006062-29D	Bushing - timing intermediate gear
3701100-A0P-HYB20	Generator assembly
1005120-E06-2001	Flywheel comes with ring assembly
1004100-BA0-0000	Connecting rod assembly
1002072-B4L-AS10	Gear chamber gasket
3701001AB71-HT1A	Generator support
1004011-B5G-0000Z	piston
MM65077P-PJGG	MM65077P cylinder head fitting
3701325CB48-AS20	Connecting plate assembly
1007035A29D	Catheter seal ring
1119069-M01	Bolt - Engine intake pipe
3509010-470-JK10	Air compressor assembly
1010010BE00-0000	Oil collector assembly
1004011AM18-0000M	piston
1308010-B21-0000X	Fan assembly
1308010B051-0000H	Fan and fan clutch assembly
1003013-96E	Exhaust valve seat
F4070000-PJ4P	F4070000 four combination fittings
1005190A301-JH10	Shock absorber assembly
3724022AM60-0000V	Engine harness bracket 2
1023031-E00-0000B	Wedge belt
F4070000-PJ6P	F4070000 six combination accessories
1308032-001-001D	Fan belt
1009060-720-YT10	Oil gauge tube assembly
3724080-485-239KA	Engine harness assembly
3724410DM70-000J	Motor harness assembly
1004001AA34-0000	piston
3601115-M60-0000	Engine control unit assembly
1129DDDD621-0000	High pressure tubing assembly
1601300-E05-2010	Clutch driven disc assembly
1005015-M50-0000	Crankshaft with oil pump drive gear assembly

3701010-051-2010	Integral alternator
XA17SG10-PJTT	A17-SG10 cylinder block fittings status
1210110-E22-2010F	DOC pre-packaged assembly 6.77X4
1118060AM40-0000	Supercharger inlet line assembly
3701010-A61-KM1A	Generator assembly
3601030-M4Q-0000	Exhaust gas bypass valve assembly
1111010A450-WP30E	Fuel injection pump Assembly (9400366948)
1160100-M60-JH20F	Urea tank module components
1129110-556-0000	High pressure oil rail assembly
K0510000-PJZW	AKZ spindle tile (sleeve)